

- The user may change the transmission rate of expansion Analog I/O module according to the application need;

Let M1911 = 0, the transmission rate is 57600 bps (System default)

M1911 = 1, the transmission rate is 28800 bps

In some applications, if it needs more than 15 pieces of expansion temperature module ( 2AJ4/2AK4/2AH4/2AT4), the user must let M1911 be ON to guarantee the analog input readings.