


1.7.11 Communication Board (CB)


[DB9F/3Pin plugable terminal block] (Below are outlooks of CB and the corresponding cover plates)

- 1 RS232 port




FBS-CB2

- 2 RS232 ports




FBS-CB22

- 1 RS485 port




FBS-CB5

- 2 RS485 ports



FBS-CB55

- 1 RS232 + 1 RS485 ports



FBS-CB25


1.8 Drawings with External Dimensions

(1) Outlook I :

Main Unit : FBS-10M△, FBS-14M△

Expansion Module : FBS-16E△, FBS-20EX

* (Main Unit and Expansion Module have the same type of base, with different top cover, as shown in the figure)




units : mm

(2) Outlook II :

Main Unit : FBS-20M△, FBS-24M△, FBS-32M△, FBS-40M△, FBS-60M△

Expansion Module : FBS-24EA(P), FBS-40EA(P), FBS-60EA(P), FBS-TC16, FBS-RTD16



units : mm

W	Model
90mm	FBS-20M△, FBS-24M△, FBS-24EA(P), FBS-TC16, FBS-RTD16
130mm	FBS-32M△, FBS-40M△, FBS-40EA(P)


(3) Outlook III :

Expansion Module : ① FBS-8E△, FBS-7SG△, FBS-6AD, FBS-2DA, FBS-4DA, FBS-4A2D,
FBS-TC6, FBS-RTD6, FBS-CM5H

② FBS-24EX, FBS-24EYT, FBS-32DGI

* (Modules ① and ② have the same type of base, with different top cover.


Top cover of Module ① is shown in the following figure)



(4) Outlook IV :


Communication Module : FBS-CM22, FBS-CM55, FBS-CM25, FBS-CM25E, FBS-CM55E,
FBS-CM25C, FBS-CM5R

* (All modules have the same type of base, with different top cover. Top cover of Module -CM25E is shown in the figure)



units : mm

(5) Outlook V :
 Programming Panel : FP-07C



units : mm

(6) Outlook VI :
 Data Access Panel : FB-DAP

