

## **WinProladderV2.40 Function change explanation**

### **Increases Function instruction**

F34.MLC (Multiple Linear Conversion)

### **Additional function: Below increases the function**

- 1.Increases FBs-1LC and FBs-VOM module's setting.
- 2.Addition [Check power supply capacity] function key.

### **Revision function: Below revises the function**

- 1.The revision works as [Connect to PLC], and non-open the associated project file, execute table instruction's inspection and reconstructing table's content.
- 2.The revision works as before enters [ROR Register], inspection from the ROR were used by table function, and move the table's content to ROR.
- 3.The revision works as after confirmation from table edition, the tree-view on left side maintains the previous position.
- 4.The revision works as under [Element Comment] or [Element Statistics], records the previous cursor position.
- 5.The revision works as under [Off-Line], display the item's value of [Status Page].
- 6.The revision works as writing code to ROM\_PACK need input the PLC ID.

### **Wrong correction: Below corrects the mistake**

- 1.The correction works as because the plant serial number cause to communication error of the Reject Access.